

Easyriser parts list Model 4000

<u>Part#</u>	<u>Description</u>	<u>Req Qty</u>	<u>Each</u>
23	Wing connector, trailing edge	2	14.00
24	Wing connector, leading edge	2	10.00
31	Rudder bearing assy, upper	2	14.00
32	Rudder bearing assy, lower	2	14.00
33	Strut bracket, 1" no rivnut	8	7.00
34	Strut bracket, bottom rudder, rivnut	2	8.00
35	Strut bracket, 1", rivnut	2	7.00
36	Strut bracket, 1.50" no rivnut	2	8.50
37	Strut bracket, 1.50", short rivnut	8	9.00
38	Strut bracket, 1.50" long rivnut	2	9.00
39	Gusset hang tube front slotted/no slot		12.00
40	Gusset, hang tube rear slotted/no slot		12.00
41	Gusset, dia front	8	3.00
42	Gusset, dia, rear	4	3.00
43	Gusset, root tube front	8	3.00
44	Gusset, root tube rear	4	3.00
53R	Wing rib R/H	13	25.00
53L	Wing rib L/H	13	25.00
54	Rib rudder front	6	3.50
54L	Rib rudder top	2	3.50

55 Rib rudder main	8	4.50
56 Rudder LE	2	7.00
56l Rudder TE	2	7.00
61 Wing root, R or Left	4	17.00
62 Wing diagonal upper or lower	4	18.00
63 Wing tip L	2	22.00
64 Wing tip R	2	22.00
66 Wing strut 45"	10	23.00
67 Wing strut 44.50" Inner diag	2	23.00
68 Wing strut, outer diag	2	23.00
69 Strut, rudder assy 44.50"	2	23.00
70 TE spar inner sleeve for elevator (optional)	4	3.00
 Lishman Elevator MOD	 *1	 840.00

* Inquire as to List of parts and quantities.